

Product Features


- Using 2.4G RF remote control, long distance transmission
- Available to dimming the lights full-color & brightness
- Remote control four groups individually
- Remote control is stylish and convenient to use


Technical Parameters


Item	Parameters
Power	3VDC(AAA*2pcs)
Remote Distance	30m
Wireless Frequency	2.4Ghz ISM
Working Current	<20mA
Standby Current	<10uA
Standby Time	6 months
Working Temperature	-30℃~55℃
Dimension	122*53*17.5mm (L *W *H)
Weight	135 g


Remote Control Button





 : Short press turn on/off current zone light, long press 2s turn off all zone light.


 : Touch to change current zone static RGB color.


 : Short press select and turn on zone light, long press 2s turn off zone light. Continuous short press multiple zone key, can synchronous select multiple zone.

 : Adjust R/G/B brightness, short press turn on/off, long press 1-5s continuous 256 levels adjustment.

 : For RGB light, short press turn on/off white(RGB mix), long press 1-5s continuous 256 levels adjust saturation, namely change current static color to mixed white slowly. For RGBW light, short press turn on/off W channel, long press 1-5s continuous 256 levels adjust W brightness.

 : Adjust mode for current selected zone, Short press run next RGB mode, long press 2s run mode-cycle.

 : For static color, adjust brightness, short press 10 levels, long press 1-5s continuous 256 levels adjustment. For dynamic mode, adjust speed, short press 10 levels, long press 2s the fastest speed.

 : Short press run the scene, long press 2s save. 4 zone run or save synchronously.



Cod. / Код. : F6011003-013

1. Match Code and Grouping :

The remote control can be used after matching the code with the led driver, the method is as following:

Choose the led driver that you want to divide the group, turn off the power for 10 seconds, then turn on the LED driver, Within 3 seconds , press the corresponding " Group ON " button quickly for 3 times, the lamp connected to the LED driver will flick slowly for 3 times. Then, confirm the success of matching code. The other groups can also be set by the same method.

2. Clear Code and Regroup :

If the room layout are changed, or you want to make a little adjustment upon your fond, then you may want to change the previous groups. Before regrouping, you need to clear the code, the method is as following:

Choose the led controller you want to clear the code (if more than one driver needs to be clear, the operation is performed at the same time.) turn off the power for 10 seconds, then turn on the power again. Within 3 seconds, press the " All ON " button quickly for 6 times, the lamp connected to the LED driver will flick quickly for 6 times, then the code is cleared successfully. After the code is cleared, the method of setting the group is totally the same as the principle of "matching the code and grouping"

Attention

When install the batteries, please don't touch the color ring or any key and use the remote 5 seconds later after batteries installed. If the touch key or ring is low-sensitive, please reinstall the batteries in the right way.